

INSTALLATION GUIDELINES

Boulevard B3 Top Trim with Embedded Glass installation

STEP 1: Remove both top trims from the panel. Proceed carefully from one end, progressing to the opposite end. Be mindful of not bending the top trim.

STEP 2: Insert the glass and center it on top of the panel.

There is one gasket at either end of the panel as well as several polycarbonate brackets positioned along the top horizontal channel. Ensure that the glass has been pressed all the way to the bottom of the gaskets/brackets.

STEP 3: Use the special allen key (supplied with each Top Trim Embedded Glass Panel) to secure the glass in a plumb, vertical position. All set screws are furnished with nylon tips to protect the glass.

STEP 4: Leave the special allen key in the top horizontal channel for future adjustments.

STEP 5: Snap both top trims back in place on the top of the panel. Start at one end and carefully proceed to the opposite end.

