



Height Adjustment Control

To raise chair shift body weight up, pull lever up.
To lower chair, remain seated and pull lever up.

Tension Control Knob

Turn clockwise to increase tension and counterclockwise to decrease tension.

Tilt Control

Lift lever, push back to desired position, and push lever down to lock.